

Connecting with Ford IDS Tool (1 page summary)

1. Open Ford IDS program.
2. Select “Manual Vehicle Entry”.
3. Select the check mark in bottom right corner or press ENTER to continue.
4. Select “All Other”.
5. Enter vehicle Tear Tag “VBW0”
6. Select the check mark in bottom right corner or press ENTER to continue.
7. Select vehicle Model Year.
8. Select “Yes” to confirm vehicle details.
9. In this screen, the VIN should be a series of “#” signs. Do not enter anything, then select the check mark in bottom right corner or press ENTER to continue.
10. The Ford IDS tool is connected. To read PCM codes:
 - a. Select the Red Tool Box icon at the top of the IDS program
 - b. Select “Self Test” then “All CDMTCs”