

1. Complete a Service Ticket on the Landi Technologies Service website
2. Flash the PCM with the as-built data on gasoline using one of the following methods:
 - * Providing the vehicle to a Ford dealership for flashing OR
 - * Using the Ford FDRS tool by following Ford GSB 0000150. The engine serial number and transmission ID number will need to be inputted as part of the process.
3. After successfully flashing the PCM with the gasoline calibration, the MYCANIC tool needs to be used to flash the PCM. Landi can loan the MYCANIC tool if necessary. MYCANIC tools instructions provided separately.

NOTE: There can only be ONE .bin file on the SD card at a time. If there are any questions/issues, please have whoever is handling this reach out to service@landitechnologies.com.

Please contact Landi Technologies service department for CNG file.