

MAGNET FEET LANDING PAD INSTALLATION



STEPS

1. Use supplied template to align landing pad discs.
2. Fasten using Sikaflex, adhesive, 3M VHB adhesive tape, or three #8 screws per pad (not included).
3. Remove and discard template.
4. Align and attach magnets to centers of pads.

Hope you enjoy your new hardware!
Reach out to us with any questions/concerns to: info@uniquecomponentry.com

