



SPEC SERIES RULES V2.5

Chassis	<p>Tamiya TT01-E series chassis only. Kit must be assembled as per the instruction manual. Only modifications allowed:</p> <ul style="list-style-type: none"> • Battery tray & strap may be modified to accept 'square' or shorty battery packs. • You do not have to use the included motor heat guard.
Motor and ESC	<p>Motor must be the Tamiya Torque-Tuned brushed motor (as supplied in the kit). Motor must not be modified or tampered with in any way. ESC must be the Tamiya TBLE 02S or Hobbywing HHBQ6021 WP-1040 (as supplied in the kit). You can use any type of battery connector.</p>
Wheels & Tyres	<p>Must be the MRC NZRCS Radial Control Tire pre-mounted tyres - Yellow (hard).</p>
Gearing	<p>Only the 61T spur gear (as supplied in the kit) must be used. A 19T pinion must be used. Can be upgraded to a hard anodised aftermarket version.</p>
Batteries	<p>Any 2S / 7.4V Lipo - including shorty packs.</p>
Body	<p>Tamiya Racing Truck bodies: Team Hahn Racing MAN (#51606) / Buggra Fat Fox (#51613) / Mercedes Benz MP4 (#51654). or Bittydesign IRON Euro Truck (BDTRK-190IRO). Bodies must be trimmed to the manufacturers original trim lines as per the instructions. No lowering of the cab is allowed - by trimming, or heating & reshaping. No rear wings are allowed (<i>also applies to the Bittydesign wing</i>). Screws may be used to strengthen the joining of the body panels. Additional foam may be added to the front bumper to support the body.</p>
Hop-up Options	<p>The following parts are the ONLY hop-up parts allowed:</p> <ul style="list-style-type: none"> • Steel Bearings. • Aluminium Centre Shaft set (#54026). • Metal Motor Mount (#53666). • 2 degree Toe-in Rear uprights (#53673). • Any Servo Saver/Horn and suitable turnbuckle steering link (from servo saver only).