

Dogwood Racing Velocity Stacks with Nitrous Ports

- If the stacks were shipped without clamps, they were designed to be used with your factory clamps.
- Line up the flat sections of the stack while assembling.
- The aluminum port inserts are 1/16 npt to match NOS fan spray nozzles.
- In order to “clock” the nozzles with the fan spray facing the bottom of the port, wrap the 1/16npt portion of your nozzle with thread tape. This will open up the range where the nozzles can seat properly when clocked correctly.
- Check for proper clearance around the stacks to all other components

Intended for off road use only. Dogwood Racing, owners or managers are not responsible for any damage or costs associated with improper use or installation.