

Dogwood Racing ZX14 Velocity Stacks Factory Frame

- Line up the flat sections at the top of the stacks between cylinders 1 2 and 3 4
- Use the factory clamps to connect to the throttle bodies
- Push the O ring down tight to the air box while fastening each stack
- Check for proper clearance around the stacks to all other components

Intended for off road use only. Dogwood Racing, owners or managers are not responsible for any damage or costs associated with improper use or installation.