

Handle: Sits inside the ends

$\frac{3}{4}$ ' x 1- $\frac{3}{4}$ " x 15- $\frac{3}{4}$ "

Pattern will print on a 8- $\frac{1}{2}$ x 11"
paper, The actual length of the
pattern should be 11- $\frac{1}{2}$ "

Adjust accordingly

Antique Tool Box Pattern
Jim Viebrock
Maintenance Minute

Sides: Attach to the outside of the box and cover
the bottom. 2- $\frac{3}{4}$ " x 17' You will need 2

Bottom sits inside of the ends and sides:

5- $\frac{1}{2}$ x 15- $\frac{3}{4}$ "