

BAKUP-USA

INSTALLATION GUIDE BMW K1600 BAGGER DRIVER'S BACKREST

1. Remove the driver seat and place upside down on a work bench.
2. Remove the 2 bumpers. Second set from the back of the seat. Seen in figure 1
3. Using a 5/8" or 15.5mm drill bit, (be careful to hold the drill center while drilling) drill out the 2 holes shown in figure 1
4. Well nut installation:
 - a. Place well nut fastener all the way into pre-drilled holes until flange is firmly against mounting surface.
5. Starting from the rear of the seat, slide the backrest over the seat so that the holes in the backrest align with the well nuts. Please note the backrest will fit tightly. You may need to use a small amount of force.
6. Once the backrest is in place, install one of the bolts provided and tighten so that the well nut is secure enough that it holds it in place. Install the second bolt and tighten even to the first. Then torque both to 25 in/lbs
7. Place the two bumpers provided flat side down into the depressions shown in figure 2.
Note you may want to add a small amount of glue to the bottom of the bumpers.
8. Re-install your seat and adjust to your liking.

GET ON YOUR BIKE AND RIDE !

****PERIODICALLY** CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**

