

# **BAKUP – USA**

## **INSTALLATION GUIDE**

**BMW K1600 BAGGER PASSENGER**

1. Place bike in safe position.
2. Remove the (4) screws in back of the passenger grab rails.  
\*\*Requires T-30 Torx
3. Install (2) long spacers in the front and (2) short spacers in the back.
4. Position backrest so the mounting holes align with the spacers.
5. Insert screws  
\*\*Be sure to start all 4 screws before tightening.
6. Tighten all screws.  
\*\*Requires 10mm wrench
7. Adjust backrest to your liking.

***GET ON YOUR BIKE AND RIDE!***

**\*\*PERIODICALLY\*\* CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE THEM TO LOOSEN –  
THANKS**