

# **BAKUP-USA**

## INSTALLATION GUIDE BMW 1600 GRAND AMERICA DRIVER'S BACKREST

1. Place bike in a safe location.
2. Remove the Driver's seat and place upside down.
3. Remove the 2 bumpers shown in the picture.
4. Using a ½" or 12.5mm drill bit (be careful to hold the drill center while drilling) drill out the 2 holes to fit the well nuts.
5. Install the 2 well nuts provided into the holes.
6. Starting at the front of the seat, slide the backrest over the seat so that the holes in the backrest align with the well nuts. Install the 2 screws and bumpers provided with your backrest.
7. Reinstall your seat and adjust to your liking.

**GET ON YOUR BIKE AND RIDE !**

**\*\*PERIODICALLY\*\* CHECK SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**