

**BAKUP-USA**  
**INSTALLATION GUIDE**  
**BMW R1200GS ADVENTURE**  
**WATER COOL PASSENGER**

- 1. Remove two back screws from rack.**
- 2. Place provided washers over holes on rack.**
- 3. Place backrest so holes align.**
- 4. Insert the new hardware provided.**
- 5. Screw tightly.**
- 6. Adjust backrest to your liking.**

**GET ON YOUR BIKE & RIDE !**

**\*\*PERIODICALLY\*\* CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE THE SCREWS TO LOOSEN**