

BAKUP-USA

BMW R1200R WC DRIVER INSTALLATION GUIDE

1. Remove pillion seat.
2. Center backrest in front of pillion seat.
3. Mark holes to be drilled. ***VERY IMPORTANT***
**make sure the backrest is centered
before marking.**
4. Drill 2 half inch holes where you marked.
5. Insert the 2 well nuts included with the backrest.
6. Place backrest over well nuts. Insert the 2 screws provided.
7. Tighten screws. Adjust backrest to your liking.

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**