

BAKUP-USA

BMW R1200R WC PASSENGER INSTALLATION GUIDE

1. Place (4) four spacers provided above the (4) holes in the luggage rack.
2. Set your backrest on top of the spacers so that the (4) holes align.
3. Install (4) screws provided. Tighten screws.
4. Adjust backrest to your liking.

GET ON YOUR BIKE & RIDE !

****PERIODICALLY** CHECK THE SCREWS ON PADS BECAUSE VIBRATION MAY CAUSE SCREWS TO LOOSEN**