

UNPLUG THE POWER TO YOUR HEATER BY SHUTTING OFF THE CIRCUIT BREAKERS!!!

BE CAREFUL WHEN REMOVING CONNECTORS – OLD CONNECTORS ARE BRITTLE!!

AVOID DAMAGING YOUR BOARDS DUE TO ESD USE OF A ESD STRAP AND ESD SMOCK ARE HIGHLY RECOMMENDED!!!

1. DISCONNECT THE POWER TO YOUR HEATER
2. REMOVE YOUR OLD PANEL. The boards are attached to it.
3. TAKE A PIC OF THE CONENCTIONS AS YOU REMOVE THEM SO YOU KNOW HOW TO RECONNECT YOUR NEW PANEL.
4. Unplug the connections and remove your boards. Handle boards carefully as they are subject to ESD damage.
5. Install the boards to your new panel.
6. Plug the connections back in IN THE EXACT MANNER THAT YOU UNPLUGGED THEM INCLUDING THE NEW KEYPAD CONNECTOR
7. Turn your power back on