

Competitive Cross Reference

| PAD TYPE | NORTON | 3M | GLIT | MICROTRON | ETC | AMERICO | ACS/SCRUBBLE |
|------------------------|----------------------------------|----------------------------|--------------------|----------------------------------|---------------------------|-------------------------------|-------------------------------------|
| Stripping | Ultra Blue Stripper | N/A | High Performance | Emerald Stripper | Boss Hawg Stripper | Dominator | N/A |
| | High Productivity Black Strip | 7300 High Productivity | Safire Stripper | Ultra 66 High Performance | Razorback | HP500 Heavy Duty Stripping | Type 73 Emerald Hy-Pro |
| | Black Super Strip | 7200 Black Stripper | Black Strip | VL Black Strip | Black Strip | Black Stripping | Type 72 Black Strip |
| Scrubbing/ Cleaning | Green Super Scrub | 5000 Topline Pre-Burnish | Green Scrub | VL Green Scrub | Green Scrub | Green Scrub | Type 55 Green Scrubber |
| | Blue Super Clean | 5300 Blue Cleaner | Blue Cleaner | PL Blue Scrub | Blue Cleaner | Blue Cleaner | Type 53 Blue Cleaner |
| Buffing/ Polishing | Red Buffer | 5100 Red Buffer | Red Buff | PL Reg Red Spray Buff | Red Buff | Red Spray Buff | Type 51 Red Buffer |
| | White Super Gloss | 4100 White Super Polish | White Super Polish | PL White Fine Polish | White Polish | White Polish | Type 41 White Polishing |
| | Tan Buffer | N/A | Tan Buffing | VL Tan Buff | Tan Buff | Tan Buffing | Type 34 Tan Buffer |
| Burnishing | Pink Topshine Burnish | 3200 Topline Speed Burnish | Peach Buffing | PL 40-D Red | N/A | N/A | N/A |
| | Ultra Grizzly Bear | 3500 Natural Blend Tan | Buckaroo | Natural Fiber Buff | Gorilla | Porko Plus | Type 37 Hair Blend Extra |
| | Grizzly Bear Lite | 3300 Natural Blend White | Jackeroo Lite | Natural Light | Gorilla Lite | Combo | Type 33 Hair Blend Light Thermal |
| | Thermal Burnish | 3400 Tan Burnish | Joey | UHS Tan | Super Speed Rubberized | Image Beige Burnishing | Type 42 Beige Poly |
| | Aqua Ultra High Speed Burnish | 3100 Aqua Burnish | UHS Beige | PL High Speed Yellow PI Beige | Aqua Plus | N/A | Type 31 Aqua Burnishing |
| | Mint Soft Burnish | 3600 Eraser | Blue Ice | Blue Ice | Blue Jay | Luster Lite | Type 36 Pink Burnishing |
| | Champagne Polish & Burnish | 4200 Beige Buffer | Champagne | VL UHS Aqua | The Cure | Yellow High Speed | N/A |



Top Performance. Great Quality. Exceptional Value.

NORTON Floor Care Procedures

Stripping Application

- 1. Set caution signs
- 2. Remove foreign debris from floor and dust mop
- 3. Prepare stripper solution as directed by manufacturer
- 4. Apply stripper solution around baseboard and hard to reach areas
- 5. Use a utility pad and holder to strip. Do not let stripper dry
- 6. Apply stripper solution to a manageable area following product dwell time instructions
- 7. Strip with floor machine and proper stripping pad
- 8. Remove solution using a wet/dry vacuum or an auto-scrubber
- 9. Rinse floor with clean water, changing water frequently and allow to dry
- 10. Dust mop and inspect floor before applying finish



Ultra Blue Stripper, High Productivity Stripping, Black Super Strip

Scrubbing / Cleaning Application

- 1. Set caution signs
- 2. Remove foreign debris from floor and dust mop
- 3. Prepare scrubbing solution as directed by manufacturer
- 4. Apply scrubbing solution using a mop and bucket or an auto-scrubber
- 5. Scrub floor with proper scrubbing/cleaning pad
- 6. Remove solution using a wet/dry vacuum or an auto-scrubber
- 7. Rinse floor with clean water or neutral cleaner and allow to dry
- 8. Dust mop floor before applying finish or buffing



Green Super Scrub, Blue Super Clean

Spray Buffing / Polishing Application

- 1. Set caution signs
- 2. Remove foreign debris from floor and dust mop
- 3. When spray buffing, apply solution only to an area easily maintained by a single person
- 4. Immediately buff floor with appropriate buffing pad
- 5. Use side to side overlapping motion
- 6. Dust mop floor after buffing for final inspection
- 7. For high gloss shine repeat steps 4 through 6 with a White Super Gloss pad



Red Buffer, White Super Gloss

High Speed Burnishing Application

- 1. Set caution signs
- 2. Remove foreign debris from floor and dust mop
- 3. Burnish floor with appropriate burnishing pad per floor maintenance schedule
- 4. Dust mop floor after burnishing for final inspection



Champagne Polish & Burnish, Mint Soft Burnish, Aqua UHS, Thermal Burnish, Grizzly Bear Lite, Ultra Grizzly Bear, Pink "Topshine" Burnish

www.nortonprocleaning.com