Arming M228 or similar Head for smoke signal device **Small Pistol Primer Primer Insert** Can use a small bead of silicone to seal to head Fuse should be set Just below vent hole Fuse return about one inch. Can use Thin strip of electrical tape to hold down Fuse tube can be to fuse tube cut to desired length Using tubing cutter and deburred Use super glue to set fuse