Welcome To





Components of an Atom

Nucleus


The center portion of an atom containing the protons and neutrons

Protons

Positively charged atomic particles

Neutrons

Uncharged atomic particles



Electrons


Negatively charged particles

Electron Orbitals

Orbits in which electrons move around the nucleus of an atom

Valence Electrons


The outermost ring of electrons in an atom



Electron

Orbits


	
Orbit	Maximum
Number	Electrons
1	2
2	8
3	18
4	32
5	50
6	72
Valence	8
Orbit	
	1



Orbits closest to the nucleus fill first


Electron Orbits

Atoms like to have their valence ring either filled (8) or empty(0) of electrons.



Electron Orbits





How many electrons are in the valence orbit?

6

Is Sulfur a conductor or insulator?


Insulator

Why?

Electricity at the Atomic Level


Electron Flow


Electricity is created as electrons collide and transfer from atom to atom.



Play Animation


The flow of electricity





How do we get Electricity?

- Energy from one of the sources is converted by machines at the power plant to Electricity and then put onto the Electric Power Grid
- Electric Power Grid
 - Power Plants
 - Transmission Lines
 - Substations
 - Power Lines
 - Transformers
 - Electrical Wiring and Circuit Box



The four most basic physical quantities in electricity are:

- Voltage (E)
- Current (I)
- Resistance (R)
- Power (P)


Each of these quantities are measured using different units:

- Voltage is measured in volts (V) designated as (E)
- Current is measured in amps (A) designated as (I)
- Resistance is measured in ohms (Ω) designated as (R)
- Power is measured in watts (W)

	FLUID (OUR WORLD)	ELECTRICITY
Pressure	PSI or Ft of Head	Volts (Electromotive Force)
Flow	GPM or CFS	Amperes (AMPS)
Resistance to Flow	Head Loss Feet	Resistance (OHMS)
Quantity	Gallons or CF	KWH


How you should be thinking about electric circuits:

Current: the actual "substance" that is flowing through the wires of the circuit (electrons!)




Electric Current (I)





- ➤ This is the flow of electric charge
- >{In a metal conductor it is the flow of electrons}

AMPERE (CURRENT)



OF MOVING ELECTRONS

(OR ELECTRIC CHARGES)

Volt


- Creates The Potential Difference
- The Electromotive Force Which Must Be Applied To Create Flow Of Electrons
- Commercial Current Is 120 V or 220 V

Amps and Volts

Electricity is to home electrical circuits as water is to home plumbing systems. The voltage is roughly equivalent to the <u>water pressure</u>, and the amperage, or current, to the quantity of water that flows past a given point per second. At a given pressure, less water can get through a small pipe than a large one in a given time, so the size of the pipe can be regarded as equivalent to a measure of <u>electrical resistance</u> — a smaller pipe has higher resistance. The higher the electrical resistance of an appliance, the lower its current will be, and resistance is often dependent on the diameter of the wires.

How you should be thinking about electric circuits:

Voltage: a force that pushes the current through the circuit (in this picture it would be equivalent to gravity)



Watts: Rate of Power

Watts: Unit of *electrical power*, the rate at which energy is being used or generated.


Watts is the Product of Volts and Amps

Volts x Amps = Watts

12 volts x = 5 amps = 60 watts


How you should be thinking about electric circuits:

Resistance: friction that impedes flow of current through the circuit (rocks in the river)





Resistance = Electrical Impedance

- Opposition To Flow Of Electrical Current
- Measured In Ohms
 - Ohm's Law Current Flow= <u>Voltage</u>
 Resistance










$$\mathbf{I} = \frac{V}{R}$$



$$\mathbf{R} = \frac{\mathsf{V}}{\mathsf{I}}$$

Finding Voltage

Ohm's Law Formula for Finding Voltage

- (E) (I)
- (R)


Voltage = Current x Resistance

To find Voltage Multiply the Current times the Resistance.


 $E=I \times R$

Using the Magic Circle

Cover the E to see the mathematical relationship between Voltage and Current





In this first example, we will calculate the amount of current (I) in a circuit, given values of voltage (E) and resistance (R):




What is the amount of current (I) in this circuit?

$$1 = \frac{E}{R} = \frac{12 \text{ V}}{3 \Omega} = 4 \text{ A}$$








HOW WASTEWATER PLANTS USE ELECTRICITY

How to Calculate your Electric Cost



Power - Power Factor



Mug Capacity = Apparent Power (KVA)

Foam = Reactive Power (KVAR)

Beer = Real Power (kW)

Power Factor = $\frac{\text{Beer (kW)}}{\text{Mug Capacity (KVA)}}$

Utilities have to generate kVA, but consumers can only use kW!

kVAR penalties are enforced by the utility!

Power factor is an expression of energy efficiency. It is usually expressed as a percentage—and the lower the percentage, the less efficient power usage is.

What is Your Power Factor?



-5758 NRWER RD

-WATERVILLE OH 43586

-BIFO: MUMEESEWAGER ANTILLO/SCTV

•Bill Based On: Actual Meter Reading

•October 23, 2019 T14

Account Number: 110 019 442 976

•Page 1 of 2

•Amount Due \$77 r:27Z-5

•Due Date: November 22, 2019

•To report an emergency or an outage, call 24 hours a day 1-888-544-4877. For Customer Service, call 1-800-447-3333. For Payment Options, call •1-800-995-0095. Pay your bill online at www.firstenergycorp.com

*Bill issued by: Toledo Edison, PO Box 3687, Akron OH 44309-3687

	•Enessae/4.			•A~court5ummanF		
	te Payment Charge being added	to your	•Previous Balance			•84,155.10 •-84,155.10
	nount Due by the Due Date. shows specific charges for the costs of	of operav	Payments/Adjustme •Balance at Billing of			•0.00
efficiency, peak demand	d reduction, and renewable energy	y. These	•Toledo Edison	511 OCt 23, 2019		•23,870.54
charges are not new, but other charges on your bil	ut are and previously were consolida I.	ated with		Services, LLC - Consump ges	ition	•53,401.96 • 77,272.50
				lov 22, 2019 \$77,272.	50	
Energy Efficiency	1,083,424 KWH x 0.000806	873.24		, , , ,	_	
Peak Demand Reduction	1,083,424 KWH x 0.000202	218.85	Oct 16, 2019 KWH R Sao 18, 2019 KWH R	Reading (Actual)		•6,196.395 .
		1,2394	Sao 18, 2019 KWHR	leading (Actual)_		5,8.57.825 338.5 7
Renewable Energy,_	1,083,424 KWH x 0.001144	4	- Multiplier			3200
Nov 14, 2019.	ig is scheduled to occur on	or about	•KWH used			1,083,424 0.5598
 Pursuant to the recent Public U 	Jtilities Commission of Ohio (PUCO) Order in C	Case No. 14-	Metered Load in KW	Decelies (Astrol)		2,688.683 2,556.365
	Nodernization Rider (Rider DMR) was set to zero September 1, 2019. The Rider DMR amou		Oct 16, 2019 KVARHSep 18, 2019 KVARH	Reading (Actual)		132.318
	igust 31, 2019, will be refunded to customers		 Difference 	, ,		423,418 685.44
October billing cycle.		,	 Kilovar Hours Used Measured Lagging R 	eactive Demand		1,791.4
			 Billed Load in KW/KV 	'A		685.4
			Billed Reactive Dema			
				-CharciekTfoinsk	olacicat ——	
				Primary TE		150.0
				Customer (Charge	0
				Distribution	Related	8,103
				Componen	t	.91
			• <u>Billikilifi</u>	rfaratkrifforPRHd24998	reartEnettrySdfince	t3LOW-Reel
			•MidAmerican	Charges	•Po Box 8019, Davenport, I	A 52808 6.63
			•M-1111V 5.111.1CIMALC	Current Co	r Service: 1-800-432-8574 . Probable of the control of the contro	Account Number: 23,87
				p 18, 2019 Bidl Octate	2019	0.54
Additional message	es, if any, can be found on back.			24 Kwh At 0.093c Pei 83424 Kwh At 4.836c		0.54
	•saga History`				LC Current Charges	53,401.96
	A		•10/11/19 Paymen!	84 155 10		
792,88 Oct 18	p 19	99	4,448	-04, 133.10		
6	r		,	•Previous Pa	yments/ Current Amo	ount
865.06	Mav				ustments Charges D	ue
Nov 18 6	19	1,03	B•451edo Edison		543.66 23,870.54	23,870.54
747,70			 MidAmerican Energy Services, LLC 56.6 	11 44 -56 611 44 53.	401.96 53.401.96	
Dec 18 2	Jun 19	1,13	8-10tal 84,155.10 -8	4,155.10 77,272.50 7	7,272.50	
1400000 626,90	J					
Jan 19 6	w 7 _ F R r	1,02	4,621			
_56		<u>4</u>				
1000000 623 92 Feb 19		1,09	7,379			
800000		₽				
600000		H				
Mar. 19. 10831057	and the section of the second section of the section of the second section of the sec	型 _{1,14}	8,538			
	DJ FMAM J J A S					
• 2006Q9 I E-Estima	<u> </u>	_ ∐	L			
0	19 ct	1,08	8,424			
		This Y	har			
Comparis	Last Year	37.1.5g				
ons	97'1/1.1	31.1.3g				

What You Need to Know!

•	
Oct 16. 2019 KWH Reading (Actual)	6,196.395
Sep 18, 2019 KWH Reading (Actual)	5,857.825
Difference	338.57
Multiplier	3,200
KWH used	1,083,424
Metered Load in KW	0.5598
Oct 16, 2019 KVARH Reading (Actual)	2,688.683
Sep 18, 2019 KVARH Reading (Actual)	2,556.365
Difference	132.318
Kilovar Hours Used	423,418
Measured Lagging Reactive Demand	685.44
Billed Load in KW/KVA	1,791.4
Billed Reactive Demand	685.4

A. 0.5598 (Metered Load in KW) x 3,200 (Multiplier) = 1,791.4 (Billed Load in KW/KVA) B. 1,791.4 x 1,791.4 = 3,214,344.73

C. 685.44 (Measured Lagging Reactive Demand) x 685.44 = 469,828


D. 3,214,344.73 + 469,828 = 3,684,172.73


$$\sqrt{3,684,172.73}$$
 = 1,919.4

F. $\frac{1,791.4}{(Billed Load in KW/KVA)} \times 100 = 93.33\%$ Power Factor 1,919.4

Power factor correction consists of increasing a plant's power factor so that it approaches 1, usually with a target of 0.92 to 0.95. Power factors lower than this may incur a surcharge by the electric utility supplying the plant.


POWER FACTOR	SURCHARGE
90 - 100%	None
88 - 90%	2%
85 - 88%	4%
80 - 85%	9%
75 - 80%	16%
70 - 75%	24%
65 - 70%	34%
60 - 65%	44%
55 - 60%	57%
50 - 55%	72%
0 - 50%	80%








MCC-SB DeWatering Building



SANDUSKY ELECTRICAL DISTRIBUTION




Stator Windings


Rotor

End Rings

Air Gap


Stator Laminations













Motor Nameplate Data

YASKAWA ELECTRIC AMERICA, INC							
MODEL 8J 215THTL7726ET-R130 L FRAME 215TC							
POLES 4 ENC TENV CODE M DES A TYPE TTL INS F3							
VOLTS 230/460 RFM 1774 AMPS 27/13.5							
SF 1.0 DUTY CONT MAX OC 40 TEMP SENSORS T-STATS							
SERIAL AMPS 14.9/7.4							
MAX 4200 Brg. 309 Ors.E. 206 ROTOR 1.3							
HZ	HP	RPM	(LB FT)	(HIGH CONN)	(HIGH CONN)		
1	-	0	29.5	-	13.5		
60	10	1774	29.5	460	13.5		
120	10	3540	14.8	460	12.5		
OHMS PH. R1: .369 R2: .338 X1: 1.42 X2: 2.28 XM: 34.9							
P/N MTRY547							
3 PHASE INVERTER DUTY AC INDUCTION MOTOR MFG. BY MARATHON ELECTRIC MANUFACTURING CORP. WAUSAU, WI MADE IN USA B-91879							




HP- Horsepower

The horsepower figure stamped on the nameplate is the horsepower the motor is rated to develop when connected to a circuit of the voltage, frequency and number of phases specified on the motor nameplate.



RPM - Revolutions per Minute


 The RPM value represents the approximate speed at which the motor will run when properly connected and delivering its rated output



Voltage


In The rated voltage figure on the motor nameplate refers to the voltage of the supply circuit to which the motor should be connected, to produce rated horsepower and RPM.

When a motor nameplate indicates that a motor is rated 220-440, **230-460**, or. 240-480, it **means** the motor is designed to run at either the low or high **voltage** rating



Hz-Frequency


The frequency figure on the motor nameplate describes the alternating current system frequency that must be applied to the motor to achieve rated speed and horsepower.



Amps

The amp figure on the motor nameplate represents the approximate current draw by the motor when developing rated horsepower on a circuit of the voltage and frequency specified on the nameplate.


FL Amps – Full Load Amps



NEMA Design

The NEMA Design rating specifies the speed torque curve that will be produced by the motor.

National Electrical Manufacturers Association (NEMA)



Insulation Class


☐ The insulation class letter designates the amount of allowable temperature rise based on the insulation system and the motor service factor.

Insulation Class Information

■ Most common insulation classes are class B and F


Insulation Class	Ambient Temp.	Temp. Rise	Total Temp.
Α	40°C	65°C	105°C
В	40°C	90°C	130°C
F	40°C	115°C	155°C
Н	40°C	140°C	180°C

$$40^{\circ}\text{C} = 104^{\circ}\text{F}$$
 $115^{\circ}\text{C} = 239^{\circ}\text{F}$ $130^{\circ}\text{C} = 266^{\circ}\text{F}$ $65^{\circ}\text{C} = 149^{\circ}\text{F}$ $140^{\circ}\text{C} = 284^{\circ}\text{F}$ $155^{\circ}\text{C} = 311^{\circ}\text{F}$ $90^{\circ}\text{C} = 194^{\circ}\text{F}$ $105^{\circ}\text{C} = 221^{\circ}\text{F}$ $180^{\circ}\text{C} = 356^{\circ}\text{F}$



S.F. - Service Factor

- ☐ The number by which the horsepower rating is multiplied to determine the maximum safe load that a motor may be expected to carry continuously
- Example a 10HP motor with a service factor of 1.15 will deliver 11.5 horsepower continuously without exceeding the allowable temperature rise of its insulation class



Frame

 The frame designation refers to the physical size of the motor as well as certain construction features such as the shaft and mounting dimensions.

There are six main causes of electric motor failures:

Over-Current

Low Resistance

Over heating

Dirt

Moisture

Vibration

1. Over-Current (Electrical Overload): In different

irions, ela opei som o draw his un over denly ar hapı mot

devices that need to be



neir

the me vent it

from happening. These devices are usually wired in the circuits and will automatically shut down the extra amount of current flowing in the circuit. 2. Low Resistance: Most motor failu insulation resistance. This issue is co difficult one to tackle. In the initial sta insulation resistance is observed to be megaohms. After some time, the insu degrade at an alarming level becaus decay gradually. After a lot of research which can preve

devices that test


safeguard rotating

failures. It is impos

at regular interval

There are automatic time to time and nat prevents such erformance is monitored

3. Over Heating Excessive heat in motors can cause a number of performance problems. Overheating causes the motor winding insulation to deteriorate quickly. For every ten centigrade rise in temperature, the insulation life is cut in half. It has been concluded that more than 55% of the insulating failures are caused by over heating.



4. Dirt: Dirt is one of the major sources that cause damage to the electric motors. It can damage the motor by blocking the cooling fan which causes its temperature to raise. It can also affect the insulating value of the winding insulation if it settles on the motor windings. Proper steps should be taken to prevent the motors from dirt. Shielding devices are available which are used for this purpose.




5. Moisture:


Moisture also affects the performance of electric motors. It greatly contributes in the corrosion of the motor shafts, bearings and rotors. This can lead to an insulation failure also. The motor inventory should be kept dry all the time.

6. Vibration: There are a number of possible causes of vibration, such as misalignment of the motor. Corrosion of parts can also cause the motor to vibrate. The alignment of the motor should be checked to eliminate this issue

ANOTHER MAJOR REASON FOR VIBRATION IS ???








Pump oscillates due to cavitation



Cavitation damages





Sample Checks on an AC Motor



Temperature IB bearing
Temperature center motor
Vibration pen at painted spot
Check cleanliness of motor
Look at condition of junction ox an cables

Visually look for water on motor Check fan with stroboscope Listen for unusual noise

- Measure amps
- Vibration analysis with analyzer (different than pen above)
- Carefully check the base (steel) and foundation (concrete)



6 months

For example, the lifecycle energy-intensity of water in cities nationally is estimated to be 3,300-3,600 kWh per million gallons delivered and treated (Both Water and Wastewater combined).





Optimizing system processes, such as modifying pumping and aeration operations and implementing monitoring and control systems through SCADA (supervisory control and data acquisition) systems to increase the energy efficiency of equipment. EPRI (Electric Power Research Institute) has estimated that drinking water facilities can achieve energy savings of 5%-15% through adjustable speed drives and high efficiency motors and drives through process optimization and SCADA systems. In wastewater facilities, EPRI estimates that 10%-20% energy savings are possible through process optimization.

Calculating Your Own Horsepower



1. Weigh yourself. Find out how much you weigh in kilograms (your weight in pounds (your weight in pounds multiplied by 0.454) and write it down.



2.


Find a stairway that is free from obstructions. You'll be running up these stairs with a stopwatch, so try to find a stairway that is not frequently used.



3. Measure the total height of the stairs from the base to the top of the stairs (the height of one stair multiplied by the number of stairs). If you measure in feet, multiply that number by .3048 to convert to meters. Write down the height in meters.





- **4.Keep a steady pace.** Get a running start, and when your foot lands on the first step, start your stopwatch.
- •When both feet are on the top step, stop your stopwatch. Write down the duration of your climb to the top.



5.**Calculate your Wattage.** Use the formula (m*9.81*h)/t, where m=mass (i.e., your weight in kilograms), h=height of staircase in meters, 9.81 is the gravitational constant that must be taken into account, and t=time in seconds of your climb. The resulting number you get is expressed in Watts.

Example: If you weigh 180 lbs, and you climb a 12-foot staircase in 4 seconds, that equals ((180 * .454) * 9.81 * (12 * .3048)) / 4 = 733 Watts





- **6. Calculate your Horsepower.** Divide the number of Watts by 746 to find out your horsepower rating.
- •A healthy human can generate a short burst of about 1.2hp, and a sustained output of about .1hp.

