

Reflective Overlay Kit

The overlay kit is designed to be applied over the Universal Moto Decal Kit. We do not mask the overlay kit. We found it more difficult to get the placement right when the pieces were masked and due to the size, it really isn't necessary.

Because the vinyl is not protected by masking application is a little different.

To apply the overlay kit simply remove each piece from its backing, careful not to damage the edges, and apply to the desired location on your helmet.

Be sure of your placement before putting any pressure on the vinyl. Do not rub the decal to activate the vinyl as you did with the helmet decals. Instead press them into place repeatedly first, then follow with a lint free clothe to rub them into the surface of your helmet. Doing this with your bare skin can cause friction and may cause the decal to move before the adhesive has cured.

Give the decals 24 hours to cure before exposing to the elements.

Thank You for ordering from Applied Graphics. We love feedback! Please send feedback, suggestions, and photos to us at info@reflectivedecals.com

Keep the shiny side up!