

Spider Decal Application

Clean the surface you are applying the decals to with glass cleaner and a lint free clothe.

Cut out the spiders, if applying to a helmet the legs will splay during application around the helmet.



This is one of the few times we suggest applying the center of the decal to the helmet first. Above the abdomen where the legs intersect.

Work your way out from there. Press and rub the vinyl to activate the adhesive and remove any trapped air or creases.

Be thorough.

Begin peeling the masking from the tips of the legs, finishing with the body. Place an hourglass on the abdomen and give it the same pressure treatment to activate the adhesive. Or not, it's entirely up to you.



Please allow 24 hours for the adhesive to cure before exposing to the elements or washing.