

## Spider Web Application

Clean the surface the decals will be applied to using glass cleaner and a lint free cloth.

Cut the webs out with scissors, for the straight edges of the decal get as close as you can. Leave enough so you can peel it up by the point later.

We suggest taping decals in place before application so you can see how they look and make adjustments.



When your ready peel the heavy backing away from the masking and web decal. Do this slowly to ensure the webbing does not become dislodged from the masking.

Apply the inner tip first. We like to pause at this point and remove a little more masking material from between the ends of the webs. This will allow the ends to spread around the curve of the helmet.

As you apply the web from the inside working out you may see creasing, allow the masking to crease but NOT the decal.

Once the web and masking has made full contact with the helmet rub the decal with downward pressure to seal the edges and fully activate the adhesive. The decal should darken and the design become noticeably clear through the masking. **Be thorough.**



Starting with the point, peel the masking away slowly at an angle. Run your finger over the decal, it should feel smooth with no bumps or lifted edges.

**Please allow 24 hours for the webbing to cure before exposing it to cleaners, dirt or extreme heat.**

Thank you for ordering from Applied Graphics.  
Keep the shiny side up!