

Swage It S750 Install instructions

- Step 1. REMOVE ALL PRIMERS!!
- Step 2. Remove Primer System Assembly.
- Step 3. Remove Primer Slide Track Bearing.
- Step 4. Install desired swaging pin to the front of the mount.
- Step 5. Install the S750 Swager onto the press using the supplied screws and align to the to the left side of the Primer System Mount Assembly.
- Step 6. Lower the platform assembly to ensure that the swaging pin is centered in the shell plate.
- Step 7. Tighten both mounting screws.
 - While swaging the brass gently push forward on the press handle to fully seat the swaging pin into the primer pocket.
 - Do Not use excessive force as this may damage the brass case



