



Here are the recommended steps for installing the niche.

- 1 Locate the desired position for the niche. Avoid exterior walls.
- 2 Measure the recess on the niche and mark the wall board at the desired height. Keeping the niche centered between joists.
- 3 Cut away backer board.
- 4 Add blocking to the opening as needed. Horizontal blocking for support and vertical as needed for fit.
- 5 2 methods to install the niche.

Mounting on tile.

To start, install tile up to the recess opening. Allow full cure of adhesive on tile. Install the niche over the tile and into the recess. Use a premium, waterproof construction adhesive to bond to the framing, wall board, and tile surface. Loctite makes a great product. (See below)

Install the niche and brace until secure. 24 hours is full cure time for this adhesive. Once complete, seal edges with silicone caulk.

Mount niche to wallboard and frame.

Cut away the backer board to accommodate the recess. Attach the niche to backer board and framing using a premium, waterproof construction adhesive. Install niche and allow to cure. Cut tile to frame of niche. Caulk with silicone adhesive once all has cured.



Mango Tile

650 Anthony Trail

Unit F

Northbrook, IL 60062

