

BAYOU-GOAT-MOUNTS LLC

Installation Instructions

- **Locate and remove rubber mat in tray above radio.**
- **Using a torx #20 bit screwdriver, remove the two screws that hold the tray in place. Making sure to leave the tray in place.**
- **Using the diagram below cut along the dotted line.**
- **The rubber mat will only fit in to the tray one way. Place the rubber mat on the back side of the diagram using the placement holes for reference. Note! Make sure the Letters RH and LH on the rubber mat aligns with the RH and the LH on the diagram facing toward you.**
- **Then using a razor knife or scissors cut thru the diagram into the mat to form the slots.**
- **Slide mount thru cut slots in the rubber mat, Note! There's a half circle on the mount base that should be facing the driver. Place back on to the dash.**
- **Lift sides of the rubber mat and reinstall the screws and tighten.**

BAYOU-GOAT-MOUNTS LLC, P.O. BOX 2796 OPELOUSAS, LA. 70571 (337) 945-7771

bayougoatmounts@YAHOO.COM

