



HOCKEY BOARD DOCTOR
ARENA SERVICES & PRODUCTS



HOCKEY TOUGH

Puck and Tape Mark Remover



Formulated by the Hockey Board Doctor for all Arena Operators. Hockey Tough liquid cleaner breaks the bond between puck marks and the surface being cleaned. It does not contain solvents, butyls, phosphates, caustics, acids, or fillers. It is safe to use on your dasher boards, arena surfaces, HDPE, polycarbonate, acrylic, steel, aluminum, fiberglass and concrete. Hockey Tough will not harm or affect the quality of your ice!

Dasher Boards (Ice Side): Mix 1 part HT to 4 Parts water. Spray the area with cleaner and allow it to soak for 5 minutes; make sure to keep the area wet. Use a medium grit rotary scrub brush, eraser sponge, or light duty scouring pad to scrub the area. Re-apply the cleaner if needed. Rinse with water when finished. The Dr. recommends eraser sponges on smooth services because they last longer and scouring pads in rough areas like the front of boxes or behind the goals.

Aluminum Supports: Mix 1 part HT to 4 Parts water for extremely marked areas. Use 4 ounces per gallon for regular maintenance. Spray supports and allow it to soak for 5 minutes; make sure to keep the area wet. Use a light duty scouring pad to scrub the supports and wipe them clean with paper towels. An eraser sponge can also be used for this but it will blacken from the aluminum.

Dasher Board Shielding, Tempered glass, Acrylic, and Polycarbonate: Mix 4 ounces of HT per gallon of water. Spray the area and allow it to soak for up to 5 minutes; make sure to keep wet. Use a light duty scouring pad or non-abrasive window mop/squeegee to clean. The Dr. also recommends using heavy abrasive on tempered glass because they will not scratch the surface.

Goal Frames/Pads, Painted Block Doors, Steel Posts/Panels, Polyethylene Backer Panels, Vinyl Ads, Player's Boxes: Mix 4 ounces of HT per gallon of water. Spray the area and allow it to soak for 5 minutes; make sure to keep wet. Use a light duty scouring pad to scrub the supports and wipe them clean with paper towels. You can also rinse them with water after they are scrubbed.

Concrete Ice Pad Preparation: Mix 4 ounces of HT per gallon of water. Apply the solution with a floor scrubber and allow it to soak for 15 minutes. Vacuum the remaining liquid and rinse with hot water when finished.

Hockey Strong is what the Doctor prescribes and uses himself!

This chemical does not meet the hazardous criteria set forth by the 2012 OSHA Hazard Communication Standard (29 CFR 1910.1200). Handle in accordance with good industrial hygiene and safety practice. Do not handle until all safety precautions have been read and understood.

Precautionary Statements

Prevention:

Do not breathe mist or spray. Avoid contact with eyes. Do not ingest. Keep out of reach of children.

Response:

IF IN EYES: Rinse with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Call a physician if irritation persists.

IF ON SKIN: Rinse skin with water/shower if irritation occurs.

IF SWALLOWED: Call a POISON CENTER or doctor/physician if you feel unwell. Rinse mouth. Do NOT induce vomiting.

Storage: Store locked up.

Disposal: Dispose of contents/container in an approved waste disposal plant.



Hockey Board Doctor
Oakley, MI 48649
989-770-2033
hockeyboarddoctor.com