



Toyota Tacoma Engine Splash Guard Installation Notes

Step 1: Roll out both Engine Splash Guards. Identify the Passenger & Driver Side (Driver Side guard pictured below).

Step 2: Plug all pre-existing holes with your Upgraded Mounting Clips. Be sure to push the stem of the clip completely through the guard until the flat-head sits flush on top of the guard.

Step 3: Start with the top row, begin fastening each mounting clip into the pre-existing mounting holes on your Tacoma. When the top row is secure allow the guards to hang in place, then begin fastening the bottom row until securely fastened.



- *All holes will align directly with the exception of 1 – 2 per side. Those holes are slightly offset $\frac{1}{2}$ " – $\frac{3}{4}$ " to force slack into the Splash Guards. Each guard is designed to have a minimum $\frac{1}{2}$ " slack when mounted. This slack accommodates for any body to frame flexing and increases the tensile strength.*

Guaranteed and Made in Jacksonville, FL USA!

CALL OR TEXT OUR SHOP LINE (904) 497-0101 FOR ANY QUESTIONS REGARDING INSTALLATION!