



Toyota Tacoma Engine Splash Guard Installation Notes

Step 1: Roll out the Engine Splash Guards. Identify the Front and Rear Splash Guards (Front shown on the Right, Rear shown on the Left).

Step 2: Plug all pre-existing holes with your Upgraded Mounting Clips. Be sure to push the stem of the clip completely through the guard until the flat-head sits flush on top of the guard.

Step 3: Starting with the top row, begin fastening each mounting clip into the pre-existing mounting holes on your Tacoma. When the top row is secure allow the guards to hang in place, then begin fastening the bottom row until each hole is securely fastened.

- *For 3rd Gen Front Extension – Remove the clip holding the fender liner attached to the body. Replace with Upgraded Mounting Clips. Push the Upgraded Clip through the fender liner and align with the middle pre-punched hole on the Front Extension.*



- *Each guard is designed to have a 1/2" slack when mounted. This slack allows the guards to flex and increases the tensile strength.*

Guaranteed and Made in Jacksonville, FL USA!
