

## *Turbine-Style Wheel Cover Decals*

*For*

*1957 Ford Thunderbird/Fairlane*

***sliceofheavendecals.com***

**[sliceofheavendecals@gmail.com](mailto:sliceofheavendecals@gmail.com)**

### **Directions**

- 1) Clean factory-painted area with non-abrasive cleaner and microfiber cloth. Dry completely. The decal can be applied directly over the painted area.



- 2) Carefully peel decal off backing, starting at the corner of the turbine “foot” and “leg. Be careful not to stretch it.
- 3) We recommend aligning the base of the ‘foot’ of the decal first, tapping gently into place.
- 4) With light pressure, press the decal into the depression just above the ‘foot.
- 5) Then very lightly tap the “leg” of the turbine, almost to the end.
- 6) Check alignment. We recommend a small exacto-type blade or small pick tool to manipulate the decal off for repositioning. Because of the 3-dimensional shape of the turbine, placing the decal correctly will take some practice. When satisfied set the decal with firm pressure.
- 7) For the decal covering the tire valve hole, simply apply the decal as above, then use a sharp blade to trace the hole and remove the decal piece.

