

# McNASTY CUSTOMZ

Thank you for your recent purchase of the McNasty Customz HONDA TALON Lower door inserts. When Purchased with Powder Coating please keep in mind that it is just that a coating. Powder Coat is **not** indestructible and **can** scratch and chip although it is highly resistant to both. When installing the Doors there are some factors that need to be considered for a proper fit.

- Has the Buggy ever been into an accident?
- Any Aftermarket parts?
- Prior Modifications

Although we have designed them to work with most Aftermarket Accessories, we cannot guarantee proper fitment with all of them and is the buyer's responsibility to check compatibility as some modifications may be required.

**During the installation there may be some adjustment that may have to be made to the factory door as not all of them are installed or adjusted the same from the dealer. This is very simple to do so if you run into an issue when installing and you feel alignment is off please do not drill new holes in the door inserts and adjust the factory door to your liking or contact us to walk you through it.**

## **Please Visit [McNastyCustomz.com](http://McNastyCustomz.com) For an Installation Video**

1. **You will need A Drill with a ¼ Drill Bit, Clamp, and a 10mm wrench**
2. Begin the installation by removing the outer door skins of the Talon. You will see 8 phillips head screws on the inside of the door around the edges. Remove these making sure to put them someplace they won't get lost.
3. Now you are ready to install the door panels using the clamp secure the lower panels to the upper doors, this is when you will make any adjustments before drilling the bolt holes, open and close the door making sure you like the fitment, in some cases the upper door might need to be adjusted.



4. Once you are satisfied with fitment there are 4 holes on the mount edge of the lower doors. Starting at one end use the ¼ drill bit and drill straight through the plastic **(PLEASE BE CAREFUL NOT TO SCRATCH THE DOOR WITH THE DRILL CHUCK YOU CAN USE TAPE FOR EXTRA PROTECTION)**.



5. Insert a bolt from the lower door up into the upper door so the head is facing down and the nut is in the upper door. At this point check fitment again making sure nothing has moved, open and close the door.
6. Move to the last hole and repeat the same procedure drilling hole, inserting Bolt. Once you have the first and last bolts in place you can once again check fitment and finish the other 2 holes.
7. Once all bolts are secured you may now reassemble the factory upper panel, Installation is complete

McNasty Customz LLC has no control over the installation and use of the parts once sold. McNasty Customz LLC highly recommends that certified professionals install all parts that it sells. You the Buyer, agrees that you rely on your own skill and judgment in evaluating the installation of parts bought from McNasty Customz LLC, and agree that you are solely responsible for the part's use.

You, the Buyer, agree to hold the Seller (McNasty Customz LLC) harmless from, and hereby assume the entire responsibility and liability for, any and all damage or injury of any kind or nature whatever, including death, as to all persons, whether Buyer's employees, agents or otherwise, and as to all property, including Buyer's own property, caused by, resulting from, arising out of, or occurring in connection with the use by Buyer or any other person, of any parts serviced by and or purchased from McNasty Customz LLC.

Having read this agreement and knowing these facts and in consideration of Seller accepting my purchase, I, the Buyer, for myself and anyone entitled to act on my behalf, waive and release McNasty Customz LLC, its members, shareholders, officers, directors, agents, volunteers and employees, from all claims or liabilities of any kind arising out of the installation and or use of parts sold and or serviced by McNasty Customz LLC even though that liability may arise out of negligence or carelessness on the part of the Seller.