### Motor home Windscreen Privacy screen

Fitting guide



## **Step 1: Centre privacy screen**

While centring the privacy screen you want to make sure the screen wraps around your windscreen tightly

Tip: To help hold the screen in the in place you can use the windscreen wipers



### Step 2 : Mark drill holes for top buttons

With the help of a friend hold both sides of the privacy screen, then extend the elastic bands fitted in the top corners of the screen so they are tight, once tight mark a cross in the loop of the elastic.

Tip: when the band is not tight the cross should be outside the loop.





### **Step 3: Drill Top Holes**

The pop rivets supplied with your privacy screen are measured at 3/16 by 30mm, so you will require a 3/16<sup>th</sup> drill bit.

Tip: Make sure your holes are in the right position it's better to measure twice and drill once.





### **Step 4: Install buttons**

Put the pop rivet through the button making sure end of the rivet is poking through the flat side of the button. To guarantee water doesn't leak into your vehicle you are required to put Sikaflex onto the pop rivet before installing the button.

Tip: To make the remaining Sikaflex pushed out from the button smooth spit on your finger than run it around the edge of the button.







### **Step 5 : Mark drill holes for bottom buttons**

Now hook the top elastic bands over the button you put in the top of your vehicle this will allow you and a friend to pull both the bottom corners tight then pull the elastic loops tight to mark your holes using the same method from step 2.

Tip: when the band is not tight the cross should be outside the loop.





# **Step 6: Drill and install Bottom Holes button**

The pop rivets supplied with your privacy screen are measured at 3/16 by 30mm, so you will require a 3/16<sup>th</sup> drill bit. Use the same method used to install top buttons when installing bottom button.

Tip: Remember to use Sikaflex on the tip of your pop rivet and make sure your holes are in the right position it's better to measure twice and drill once.





#### All done

Now you have installed your bottom buttons your Windscreen privacy screen is ready to provide you privacy. If you have any question while installing your privacy screen, please contact our team on 0412 935 527











**AWNINGS** 

