

## **Northeast Diagramming Services TruPoint 300 Set Up Guide**

1. Pick the appropriate set up location and the operator.
2. Set up the entire instrument(Level).
3. Power on the TruPoint and be sure LAN is turned on.
4. Be sure the tablet had WIFI turned on.
5. Select the TruPoint WIFI.
6. Open QuickMap3D and create a file name
7. Be sure device is selected as TruPoint 300
8. Enter target height of “0”
9. Wait for Trupoint to connect. You should see blue chain at top of TruPoint screen.
10. Once connected you will be prompted to perform Check 1,2, and 3.
11. Check 1 is level. Check 2 and 3 are rotation calibration. Close the green on check 2 and 3.
12. Once the battery on QuickMap is green follow the next step.

You are now ready to take the first shot (Zero reference line) and plot your instrument point and control point 2. The first shot is best used to establish the “0” point. (Top of page).

Shoot reference points, then evidence, then scene.

**Make sure the last point shot is the Zero (distance) shot.** Then once done, save a ASCII & RAW.

**If you loose the 0 angle, long press the reposition triangle in QuickMap 3D.**