



C5 LED Fog Light Polarity Fix

Tools list

Required tools

- Paperclip
- Needle-nose pliers (maybe)

Suggested Tools

- WD-40, Liquid wrench or similar
- Socket extension suggested

Step 1

Identify the fog light connector and remove the gray pin lock.





Step 2

This is what the connector looks like with the pin lock removed. Note the position of the black and purple wires. Purple is the positive wire black is the ground. These will need to be reversed.



Step 3

Insert the end of the paper clip into the position shown on the fog light connector. this releases the lock on the pin allowing the pin to be removed.

Once the pin has been unlocked it should slide easily out the back with minimal force. Repeat with both pins



Step 4

Showing from a different angle.

Once both pins have been released from the connector reinsert the pins so they are in the opposite location from their original positions.

Connect the fog light and test to make sure it works. Make sure to reinstall the grey pin lock then perform the same procedure on the other fog light connector.

Enjoy!

