



Hyperflash Harness for C5 Corvette

Installation Guide

Tools list

Required tools

- Torx 15 screwdriver
- Small flat-head screwdriver
- 10mm wrench/socket
- 7mm wrench/socket
- Microfiber towel
- Jack and jack stands

Suggested Tools

- Panel-Puller tool
- Socket extension suggested
- Cordless drill with socket adapter suggested
- Creeper (or blanket/cardboard sheet unless you have a really nice garage floor)

1) Remove the two Torx 15 screws on the knee bolster.



2) Use a flat head screwdriver to gently pry out the fog/trunk switch.



3) Remove the Torx 15 screws on behind the fog/trunk switch. Disconnect the switch and set it aside.



4) Use a flat head screwdriver to gently pry off the HVAC sensor vent panel next to the ignition switch.



5) Remove the single Torx 15 screw behind the vent.



6) Release the locking tabs on the HVAC vent and gently push it backwards. Remove the knee bolster (some wiggling and prying may be required, but don't force it)



7) Locate the plugs where the Hyperflash harness will install. Disconnect these connectors and install the hyperflash harness between the connectors.



8) Turn the ignition on and check the function of the harness and lights. If everything's good, tuck the harness behind the dash and reverse the dis-assembly process to put everything back together.