



White DRL harness
for C6 Corvette

Installation guide

Tools needed

- 10mm socket or wrench
- 7mm socket
- Philips head screwdriver
- Panel pin puller (recommended)

1. Safely jack the car up and remove the wheel
2. Remove the 10mm nut on the underside of the bumper shown here:



3. Remove all of the plastic push-pins shown here



4. Remove the wheel well and lower access panel as one piece:



5. Disconnect the factory 5-pin harness and install the new harness between the factory connectors:



6. Disconnect the fog light bulb and remove the fog light assembly by removing the three 7mm screws on the bottom of the assembly (The fog light removal will allow ease of installation with another opening for your arm)
7. Mount the resistor with the supplied hardware to the opening shown here:



8. (If you ordered Gen 6 switchback bulbs) Remove the turn signal socket (seen below) and replace the factory bulb with the Gen 6 switchback bulb

9. Re-install the fog light, reconnect the fog bulb, Re-install the access panel, and headlight access panel. Check function and enjoy!

Note: The DRL function will NOT work with the parking brake on.

