



Standard Mounting Bracket Installation Instructions





Use Lag Bolts to attach Standard Mounting Bracket to Existing Wood Deck.

- For **level first step** place top of bracket 2” below top of existing deck.
- For **first step down**, determine the rise for every step, then install top of bracket that rise plus 2” down from top of existing deck.

