



Vintage Performance LLC

www.Vintageperformanceproducts.com

Honda CB350 Ignition Cover User Instructions

Thank you for your purchase of a Vintage Performance CB350 Ignition Cover.

Please follow the instructions to install your VP Ignition cover.

1. Attach the slider to the billet cover.
 - a. Use the M6x22 socket head cap screws and washers to attach the slider to the cover.
 - b. Use blue loctite on the threads of the screws & torque to 25-30 in-lbs.
2. Remove the stock cover and hardware.
3. Install the new billet cover to the motor using a stock gasket.
4. Kick the bike over a few times, then remove the cover.
 - a. inspect for any evidence of interference on the cover, specifically in the center between the cover and the rotating bolt head.
 - b. If any interference is detected, remove the crank bolt and grind the head to provide adequate clearance.
5. If no interference is detected, then re-install using blue loctite on the supplied 3, M6x40 socket head cap screws.
6. Now go race!