

Thank you for your purchase of the VP Two Stroke Silencer.

- The bolt pattern is a 3x 44mm Bolt circle, please confirm that matches the existing flange bolt pattern. If not, please purchase VP flange mounts which match the bolt pattern of the VP silencer.
- Test fit the silencer and check if the 'VP' logo is in the desired location.
 - If not, then loosen the 3x M6x200mm body bolts. (Do not remove)
 - Then rotate the aluminum body until desired orientation is achieved.
 - o Re-tighten the 3 bolts
- Install the Oring in the mounting face of the silencer
- Bolt the silencer up to the flange using the supplied hardware.
 - * If using restrictors, then sandwich the restrictor and gasket between the silencer and the mounting flange.

