



Use a small knife or spatula to separate the film from the edge of the tube so that the hook on the push rod can catch in the hole.