



## What is the proper winterizing water level?

### What To Do

1. Once it is time for the pool to be winterized it is necessary to drain the pool below the return outlets.
2. Once the directional eyeballs are removed and the plumbing lines and equipment have been blown with air, threaded plugs should be inserted tightly into the return threads.
3. At this point proper winterizing chemicals should be introduced and a good (hole free) pool cover should be placed on the pool.
4. The water level should be raised two (2) inches below the tile line.
5. This will reduce marbelite frost damage to exposed areas since the weight of the snow will raise water level to the waterline tile area.

**Superior Service And Quality For Your Dream Pool**