

How to convert from Standard bracket to Low Rider Bracket?

(Available to all 200,300,400,500,600 Series Models)

Step 1. Find 4 Bolts from bottom of Bracket (Located between Bracket and Slider)



Step 2. Unscrew total 4 bolts. Your bracket will be detached, but still air line has been connected.



Step 3. Disassemble Quick Connector (Terminate Two Rivet)



Step 4. Insert Low Rider Bracket into 4 Slider Bolts



- Do not install upside down !
- It is about 2 and ½ inch lower than standard bracket.



Step 5. Install Quick Connector to new low rider base on same spot (Use Plastic Tie to install)