

Guardrail and Barrier Wall Delineator Installation Instructions

717 (Bolt-on) - Mount into channel of W-Beam using the existing bolt that mounts the guardrail to the post. Slide the bolt

721 (Glue-on) - Adhere to W-Beam channel using our manufacturer recommended adhesive (SB-12 adhesive cement).

STR313, STR315, STR413 - Mount to wooden guardrail support post or blockout using two (2) 16 DG nails with two (2) 3/16" (0.5 cm) washers in predilled holes provided. Our Straight can also be mounted to to a metal guardrail post using our manufacturer recommended adhesive (SB-12 adhesive cement).

FR-Flex Rail - Mount over top of I-Beam or cable guardrail(notched FR) post using our manufacturer recommended adhesive (SB-12 adhesive cement).

FS-Flex Straight - Mount to wooden guardrail support post or blockout using two (2) 16 DG nails with two (2) 3/16" (0.5 cm) washers. Our FSstraight can also be mounted to to a metal guardrail post using our manufacturer recommended adhesive (SB-12 adhesive cement).

FB-Flex Barrier Marker- Adhere to top or side of concrete barrier wall or parapet using our manufacturer recommended adhesive (SB-12 adhesive cement).

FT-Flex Tab - Adhere to top or side of concrete barrier wall or parapet using our manufacturer recommended adhesive (SB-12 adhesive cement).

SB-12 Adhesive - (see adhering instructions)