

6 mil Polyfilm Installation Instructions

Be sure to read and follow installation instruction included with each carton of NexxaCore flooring.

Online instructions also available at nexascore.com/support/

- All subfloors must be dry, clean (swept of any debris), structurally sound and level **within 3/16" per 10 ft radius**.
- Concrete subfloors must be fully cured for a minimum of 60 days and tested for moisture. Moisture vapor emissions should not exceed **8lbs (ASTM F 186g)** or **90% RH (ASTM F2170) with a pH limit of 9**.
- **A minimum 6 mil polyethylene film must be used for floors outside of this range.**
- Lay film from edge of room and repeat.
- Be sure to seal overlap edges (**min 6 inches**) with water-resistant tape.

