

# WINDOW JAMB EXTENSIONS

## —TRIM RITE MFG.

### Installation Instructions



#### REMOVE JAMBS FROM PACKAGING AND REASSEMBLE

Each side is labelled (Right, Left, Top, Bottom). Make sure the line, symbolizing the front of the jamb, on each board is facing the same direction and line up each corner. Secure the corners together with the supplies screws.

#### DRY FIT THE JAMB IN PLACE TO ENSURE IT FITS

Once assembled, put the jamb into place to ensure it will fit. We also recommend placing a couple of the window clips into place as this makes it easier to secure the jamb once the silicone is applied.



#### REMOVE THE JAMB AND APPLY THE SILICONE TO THE WINDOW

Depending on your window style, the application of the silicone will vary. If you have a drywall return, apply a bead of silicone in the return. Focus on the corners and center of the return. If you do not have a return, apply a nice thick bead right on the face of the window frame. This would usually be on a manufactured groove towards the outside of the window frame.

\*Any silicone that oozes out onto the jamb will easily be peeled away once set\*



## SECURE THE JAMB IN PLACE USING SUPPLIED WINDOW CLIPS

Once the silicone is applied, lift the jamb into place and secure using the supplied clips. Hook the u-shape onto the jamb and screw the clip to your wall. Your window casing will cover the screw holes so be sure to adjust the clip as needed. Once the clips are all installed and the jamb is level, you may now apply spray foam insulation behind the jamb if you desire. \*Take caution in the amount of spray foam you apply. If you apply it too heavily, it may cause the jamb to warp.



## REMOVE CLIPS AND YOU ARE READY FOR TRIM!

Once the silicone (and spray foam if applied) is set, we like to give it at least 12 hours, the clips can be removed and the window is now ready for trim.

PLEASE CONTACT [TRIMRITE@SASKTEL.NET](mailto:TRIMRITE@SASKTEL.NET) FOR CUSTOMER SUPPORT