

Order #: 17201
Total Qty: 0

**KRBD3313S/A, KRMM3313S/A or KRBB3313S/A
PRIMARIES single faced units**

	KRBD3313S
	KRBD3313A
	KRMM3313S
	KRMM3313A
	KRBB3313S
	KRBB3313A







Order #: 17201
 Total Qty: 0

**KRBD3313S/A, KRMM3313S/A or KRBB3313S/A
 PRIMARIES single faced units**

Key	Description	No. of Parts	No. of End Pnls	Total No. of Parts
1	Designer Bolt Female	4	0	0
2	Designer Bolt Male	4	0	0

Hardware Packed By: _____

Date Packed: _____

Key	Description		No. of Parts EACH
A	End Panel		0
B	Double bin units		0
C	Markerboard unit		0
D	Faceout display unit		0

Wood Parts Packed By: _____

Date Packed: _____



Order #: 17201
Total Qty: 0

KRBD3313S/A, KRMM3313S/A or KRBB3313S/A PRIMARIES single faced units

***** Please read and review all instructions prior to starting assembly *****

- STEP 1:** Locate the 33H x 13D end panels. Begin by assembling the unit on its side: put the male part of the connector bolts into the holes from the outside and use masking tape to hold them in place. Lay the panel on the floor with the outside facing down so the threaded part of the connectors are exposed and facing up.
- STEP 2:** Take the center of the unit you are assembling and line the holes up with the exposed threaded connectors. Use the female part of the connector to hold the panel to the center of the unit and hand tighten. If assembling a starter only, then step 3 is you last step. If assembling a run of units skip to step 4
- STEP 3:** Once all female and male connectors are in place you can place the second end panel on top of the centers with the holes lined up. Secure the second panel with the male/female connectors but only until they are hand tight. Set the unit up right and remove the masking tape. Mechanically tighten all connectors using two 5mm allen tools.
- STEP 4:** Once all female and male connectors are in place you can place the second end panel on top of the centers with the holes lined up and your next center. Secure the first center section to the second panel and the second center with the 39mm male/female connectors but only until they are hand tight
- STEP 5:** Set the assembly up right and continue with any additional adder sections. Once all are assembled go back and mechanically tighten all connectors using two 5mm allen tools.



Order #: 17201
Total Qty: 0

IDI1305 Wall Display Unit

Furniture Care Recommendations from the nation's leading furniture manufacturers

- 1.) Dust frequently.
- 2.) Use a quality furniture polish approximately once a month to lessen your chance of expensive refinishing jobs.
- 3.) Clean up spills immediately. Use a blotting action rather than a wiping action.
- 4.) For cleaning use a soft, lint-free absorbent cloth.
- 5.) Avoid placing furniture in direct sun light.
- 6.) Avoid extremes in room humidity. Too high or too low humidity can cause wood to warp or glue lines to fail.
- 7.) Avoid extreme changes in temperature. Arrange furniture away from radiators, registers and air-conditioning units.
- 8.) Rotate accessories on furniture so they do not sit in the same place all the time.
- 9.) Do not place plastic or rubber objects on a wood finish-their ingredients react with those of the finish.
- 10.) Use pads, cloth or felt to protect the furniture surface from plastic, rubber, hot dishes, beverages, bookends, flowerpots and vases.
- 11.) Lift objects-do not drag them across the furniture surface.
- 12.) Never use silicone or petroleum distillate polishes.

