

2

D260 FILLET TRIM / C100 SIMULATED LEAD FLASHING

The D260 is installed wherever the deck meets an abutting wall. The C100 is installed as a wall flashing over the fillet trim.

SEE NUMBER 4&5
ON THE CURE IT
BUILD-UP DIAGRAM

SEE THE PRE FORMED CORNER SECTION OR MITRE GUIDE
FOR INSTRUCTIONS ON FITTING CORNERS.

Brickwork should be chased out
to 35mm with a stone blade.

Trim adhesive should be applied
to the back of the C100 and be
fitted into the chase over the
top of the D260.

Fillet trim should be tacked to
the deck with clout nails / staple
gun. Ensure the flange is flush
with the deck - note: 25mm
expansion gap in boards.

