

# 2

## PARAPET WALL (AT300EXT)

AT300Ext External angle trim is used for capping 90° step details such as parapets.

SEE NUMBER 7  
ON THE CURE IT  
BUILD-UP DIAGRAM

SEE THE PRE FORMED CORNER SECTION OR MITRE GUIDE  
FOR INSTRUCTIONS ON FITTING CORNERS.

Always use the correct external and internal trim for capping details ensuring that the (matt) bonding side is always face up.

Bandage over the area where the trims meet.

Always use a D300 to allow for expansion where a step or parapet meets the main body of the roof.

AT300Ext

Roofing  
Tack

Bandage

OSB3 Deck mechanically  
fixed to the wall.

AT300Ext

Trim Adhesive

D300

25mm expansion gap

For smooth, flat parapet walls F300 can be securely fixed directly to the wall using suitable masonry fixings without the OSB3 decking. The joints and fixings can be bandaged over without the need for a complete laminate over the top.

