

Non-White Marble Floor Polishing Method

Stage: 1

- Complete no.1 grinding and apply Hitek Mega Epox21 along with 10% of Hitek Hardfil powder and allow drying for 12 to 24 hours.
- Complete no.2 grinding and remove all excess epoxy.
- Apply Hitek Gloss Advancer until saturation and then apply Hitek Hardfil over the saturated surface and allow drying for 24 to 36 hours.

Stage: 2

- Complete no.3 and no.4 of polishing.
- Repeat Hitek Gloss Advancer and Hitek Hardfil for over saturation and allow drying for a day.
- Complete 5th number of polish.
- Apply Hitek MaxShine (Optional) diluted with 3 parts of water along with no.6 step of polishing.

Approximate Consumption of Materials for 1000 Sft for Non White Marble

Product	Quantity
Hitek MegaEpox21	2 Sets
Hitek Gloss Advancer	80 Litres to 120 Litres
Hitek Hardfil 100 gm	2 to 4 Pcs
Hitek MaxShine	0.5 Ltrs

Disclaimer: The above-mentioned quantities are only an approximate estimate and the actual consumption and product specification may vary depending upon the type of stone and its porosity value.