

White Marble Floor Fixing Method

- Apply 2 to 3 thin coats of Hitek HydraPearl on back surface and on all sides of the marble.
- Mix 5% to 10% of Hitek Whitefil Powder with Hitek UltraGlue SG Part A.
- Add polyester pigments if required to further match the colour.
- Mix Hitek UltraGlue SG Part B in 2:1 ratio.
- Fill the joints within 10 minutes after mixing the Hitek UltraGlue SG Part B.

Approximate Consumption of Materials for 1000 Sft for White Marble

Product	Quantity
Hitek UltraGlue SG	2 to 4 Sets
Hitek Whitefil	2 to 4 Pcs
Hitek HydraPearl	3 to 5 Ltrs

Disclaimer: The above-mentioned quantities are only an approximate estimate and the actual consumption and product specification may vary depending upon the type of stone and its porosity value.