



MOUNTING BRACKET INSTALLATION INSTRUCTIONS.

1. Mount bracket on horizontal or vertical surface. Use the 3.5" galvanized screw and 3/8 hex driver to install base plate on surface. Cut mastic pad and seal under bracket around screw holes. Attach bracket arm using provided hardware.
2. Use the paddle bit to drill a hole through the wood siding into the wall nearest the desired router location. Use a coat hanger or other rigid metal rod to poke through the sheet rock in the interior portion of the wall. This will mark your cut in location at the interior of the wall. Go inside and cut the appropriate size hole using the cut in ring. Pro tip, Hold the ring tabs facing you on the wall where you are to cut and trace the interior edge of the ring with a pencil. Using a sheet rock saw, cut the hole slightly bigger than the outline. It's always easier to cut a little larger than try and hide a hole cut too big.
3. Once your interior and exterior holes are cut, pull the starlink supplied cable from the interior of the home out to your dish location. The connection point to the dish is smaller and more manageable than the connector for the modem.
4. Once arm is secure, plug in cable to dish and mount dish on bracket arm. We suggest running the cable on the outside of the arm. Use 1/4" black screws and 1/4" hex driver to drive screws into the dish connection point where the dish and bracket arm meet. Screw through the bracket arms pre-drilled holes. This will hold your dish in place and will not harm your dish. Alternate securing method. Some people will thru bolt the dish to the bracket arm. Secure the cable to the bracket arm using supplied UV resistant zip ties.
5. Tie your cable back to your router location. Use the cable clips, zip ties and plastic wedge anchors, in conjunction with the cable clips. Keep your horizontal/ vertical runs close to plumb and level for a pro installation. Remember to leave a drip loop when needed.
6. When your cable has been secured, pull all the slack to the inside of the building. Form and secure a drip loop on the exterior. Use the black gromet to close up the exterior penetration and seal up the hole using the silicone sealant. Point the split in the gromet down. Install the whisker pass thru on the interior cut in ring.
7. Plug in the ethernet adapter if using a wired connection, power cord and cable from dish.
8. Download the Starlink app and follow the set up instructions. Enjoy your new dish and reliable, high speed Internet connection.