

Karmalac

Brass Lacquer

APPLICATION INSTRUCTIONS

- Clean brass with a proprietary brass cleaner.
- Wipe over with methylated spirit or white spirit to remove all residual cleaner.
- Apply 1 coat of Karmalac Brass Lacquer by brush. When applying to mushroom vents ensure the material is applied under the lip of the mushroom in order to prevent any edge discolouration. Leave to dry for at least a day.
- When dry apply a 2nd coat by “layering” it on with a brush to prevent “drag” from the first coat.
- Any damaged areas can be cleaned as above and Karmalac Brass Lacquer reapplied.
- Brushes can be cleaned using Cellulose Thinner.
- To remove existing Karmalac Brass Lacquer, if required, use a proprietary paint stripper.

This information is given in good faith for the guidance of users, but is without warranty or liability. Any queries should be referred to our technical department,

Karma Coatings Ltd

2 Sefton Road, Litherland. Liverpool. L21 7PG
Tel: 0151 284 9091 Fax: 0151 284 3305
Email: sales@karmacoatings.co.uk
Website: www.karmacoatings.co.uk