

997.2/991 muffler R&R



Raise the rear of the car, either with a jack and jackstands or with a lift.

- #1. Remove bracket behind rear wheel (#33 and 34.) Loosen nuts on clamp (#16) and slide the clamp onto the muffler inlet pipe, about 2”.
- #2. Remove the 2 nuts (13mm) on the lower part of the rear bracket. Only remove the two that are holding the bracket. Pull the bracket back to release it from the bolts.
- #3. Remove the 2 nuts (13mm) on the front bracket right behind the wheel.

Once the muffler is loose is it removed from below. Once removed from the car, transfer brackets over to new muffler by removing nuts/bolts (#19 and 20.) Reverse steps to install, added the tips once the mufflers are bolted onto the car.

